5 Channel RGB+CCT LED RF Controller

Model No.: V5-M

5 Channels/DC power socket input/Step-less dimming/Wireless remote control/Auto-transmitting/Synchronize



Features

FC C CE RoHS EMC RED

- DC power socket input and 5 channel constant voltage output.
- Match with RF 2.4G single zone or multiple zone RGB+CCT remote control.
- One RF controller accept up to 10 remote control.
- 4096 levels 0-100% dimming smoothly without any flash.
- Built in 10 dynamic mode, include jump or gradual change style.
- Auto-transmitting function: Controller automatically transmit signal to another controller with 30m control distance.
- Synchronize on multiple number of controllers.
- Light on/off fade time 3s selectable.

Technical Parameters

Input and Output		
Input voltage	12-24VDC	
Input current	15.5A	
Output voltage	5 x (12-24)VDC	
Output current	5CH,3A/CH	
Output power	5 x (36-72)W	
Output type	Constant voltage	

Dimming data	
5 mining data	
Input signal	RF 2.4GHz
Control distance	30m(Barrier-free space)
Dimming gray scale	4096 (2^12) levels
Dimming range	0-100%
Dimming curve	Logarithmic
PWM Frequency	1000Hz (default)


EMC standard (EMC)	ETSI EN 301 489-1 V2.2.3 ETSI EN 301 489-17 V3.2.4
Safety standard(LVD)	EN 62368-1:2020+A11:202
Radio Equipment(RED)	ETSI EN 300 328 V2.2.2
Certification	CE,EMC,LVD,RED
Environment	
Operation temperature	Ta: -30°C ~ +55°C
Case temperature (Max.)	Tc:+85°C
IP rating	IP20
Warranty and Prote	ction

Safety and EMC

W


arranty and Protection	
arranty	5 years
otection	Reverse Polarity Short circuit

Mechanical Structures and Installations




Wiring Diagram

Connect constant voltage power supply



• Connect power adapter



Note: Long press match key for 10s, RGB and CCT light can not be on at the same time. Long press match key for 15s, RGB and CCT light can be on at the same time. above operation will also restore the factory setting.

Match Remote Control (two match ways)

End user can choose the suitable match/delete ways. Two options are offered for selection:

Use Power Restart

Switch off the power of the receiver, then switch on power.

Immediately short press on/off key (single zone remote)

The light blinks 3 times means match is successful.

or zone key (multiple zone remote) 3 times on the remote.

Switch off the power of the receiver, then switch on power.

Immediately short press on/off key (single zone remote)

or zone key (multiple zone remote) 5 times on the remote. The light blinks 5 times means all matched remotes were

Match:

Delete.

deleted

Repeat again.

Repeat again.

Use the controller's Match key

Match:

Short press match key, immediately press on/off key (single zone remote) or zone key (multiple zone remote) on the remote. The LED indicator fast flash a few times means match is successful.

Delete:

Press and hold match key for 5s to delete all match, The LED indicator fast flash a few times means all matched remotes were deleted.

Application notes

1. All the receivers in the same zone.



RF remote

Auto-transmitting: One receiver can transmit the signals from the remote to another receiver within 30m, as long as there is a receiver within 30m, the remote control distance can be extended.

Auto-synchronization: Multiple receivers within 30m distance can work synchronously when they are controlled by the same remote, under same dynamic mode and with same speed.

Receiver placement may offer up to 30m communication distance. Metals and other metal materials will reduce the range. Strong signal sources such as WiFi routers and microwave overs will affect the range.

We recommend for indoor applications that receiver placements should be no further apart than 15m.

2. Each receiver(one or more) in a different zone, like zone 1, 2, 3 or 4.



Light on/off fade time

Long press match key 5s, then short press match key 3 times, the light on/off time will be set to 3s, the indicator light blink 3 times.

Long press match key 10s, restore factory default parameter, the light on/off time also restore to 0.5s.

No.	Name	No.	Name
1	RGB jump	6	RGB fade in and out
2	RGB smooth	7	Red fade in and out
3	6 color jump	8	Green fade in and out
4	6 color smooth	9	Blue fade in and out
5	Color temperature smooth	10	White fade in and out

Dual color control

CH4=Warm white LED

CH5=Cool white LED


Each channel can supply up to 72W(@24V) and white balance can be controlled as such:

Color temperature	Cool white	Neutral white	Warm white
Power distribution	CH4=0W,CH5=72W	CH4=72W,CH5=72W	CH4=72W,CH5=0W

Linear dual color tuning

Dimming curve for CCT





Malfunctions analysis & troubleshooting

Malfunctions	Causes	Troubleshooting
No light	 No power. Wrong connection or insecure. 	1. Check the power. 2. Check the connection.
Wrong color	1. Wrong connection of R/G/B/WW/CW wires.	1. Reconnect R/G/B/WW/CW wires.
Uneven intensity between front and rear,with voltage drop	 Output cable is too long. Wire diameter is too small. Overload beyond power supply capability. Overload beyond controller capability. 	 Reduce cable or loop supply. Change wider wire. Replace higher power supply. Add power repeater.
No response from the remote	 The battery has no power. Beyond controllable distance. The controller did not match the remote. 	 Replace battery. Reduce remote distance. Re-match the remote.